

BDWOF-DSTRIM



**SCAN FOR
INSTALLATION
VIDEO!**

INSTALLATION INSTRUCTIONS

1. MEASURE DISTANCE FROM THE TOP OF THE ROUGH-IN ASSEMBLY (1) TO THE BOTTOM OF TUB DRAIN HOLE.
2. ADD 2" TO MEASUREMENT TAKEN IN STEP #6 AND CUT TAILPIECE (7) TO THAT LENGTH.
3. LUBRICATE RUBBER SEALS INSIDE ROUGH-IN ASSEMBLY (1) AND INSERT TAILPIECE (7) INTO ROUGH-IN ASSEMBLY (1). MAKE SURE GASKET (6) IS FITTED ON TOP OF TAILPIECE.
NOTE: IF TUB THICKNESS IS LESS THAN 1 1/4", USE ALTERNATIVE GASKET BDWOF-DSPACER
4. MOVE TUB INTO POSITION AND ALIGN DRAIN HOLE OVER TAILPIECE (7)
5. INSERT DRAIN FLANGE (10) THRU TUB DRAIN HOLE.
6. INSERT TAILPIECE RETAINER TOOL (9) THRU DRAIN FLANGE (10) INTO THE TAILPIECE (7) AND TWIST COUNTER CLOCKWISE SO THAT THE TEETH INSIDE THE TAILPIECE ENGAGE THE SLOTS IN THE TOOL.
7. PULL UPWARD ON THE RETAINER TOOL (9) SO THAT THE TAILPIECE (7) WITH GASKET (6) IS FLUSH WITH THE BOTTOM OF THE TUB.
8. SLIDE THE TUBULAR SPANNER TOOL (8) OVER THE TAILPIECE RETAINER TOOL (9). INSERT THE TUBULAR SPANNER INTO THE GROOVES OF THE DRAIN FLANGE (10)
9. HOLD THE TAILPIECE RETAINER TOOL (9) IN PLACE WHILE TWISTING THE TUBULAR SPANNER (8) CLOCKWISE TO THREAD THE DRAIN FLANGE (10) INTO THE TAILPIECE.
10. TIGHTEN SECURELY, REMOVE INSTALLATION TOOLS (8) & (9). DROP THE CLICKER & CAP (11) INTO THE DRAIN FLANGE (10). TEST FOR LEAKS.

